

# Batteries

P/N A0696Y  
P/N A01299  
P/N A01477Y  
P/N A01011  
P/N A0673-1  
P/N A0701  
P/N A02787  
P/N A0914Y  
P/N A02461



| Battery Part Number | Beacon Used With                | User Replaceable (Y/N) | storage Life (years) |
|---------------------|---------------------------------|------------------------|----------------------|
| A0696 series        | 500-12, -12Y, -27 & -27Y        | Y                      | 5                    |
| A01299 series       | 500-27-07 series                | Y                      | 5                    |
| A0673-1 series      | 503-1 series                    | Y                      | 5                    |
| A0701               | 503-7, -19, -35, -36 series     | Y                      | 5                    |
| A01011              | 503-24 series and 503-42 series | Y                      | 5                    |
| A02461              | 00-30-C                         | Y                      | 5                    |
| A01477              | 500-32-2Y &-S                   | Y                      | 7                    |
| A02787              | 500-32-2Y-H/G series            | Y                      | 7                    |

